



## Parts List

Ref #	Key #	Detail	Qty/Unit	Ref #	Key #	Detail	Qty/Unit
14-558	001	Base Casting	1	14-558	011	Inner Cam Bearing	2
14-558	002	Right Standard	1	14-558	012	Crankshaft Adjustable Screw	2
14-558	003	Left Standard	1	14-558	013	1" Hex Head Bolts	8
14-558	004	Crankshaft Handle	1	14-558	014	1" Hex Head Bolts	2
14-558	005	Crankshaft Ball Bearing	2	14-558	015	Flat Head Phillips Screw 1 1/2"	4
14-558	006	Blade Carrier	1	14-558	016	Springs 1/2" x 2 1/2"	2
14-558	007	Top Blade	1	14-558	017	Head Hex Bolts 5/8"	2
14-558	008	Bottom Blade	1	14-558	019	Rubber Stop	3
14-558	009	Floor Guide	1	14-558	020	Cutting Guide w/Screw	1
14-558	010	Spring Block	2				

**Order by Reference # and Key # • Toll Free Order Hotline 800-444-7060**

**Bon**<sup>®</sup>  
Trusted since 1958

4430 Gibsonia Rd. • Gibsonia, PA 15044 • USA • [www.bontool.com](http://www.bontool.com)