## **INSTRUCTIONS**

## **#14-512 Linoleum Roller Transporter**

The linoleum roller transporter fits any Bon Tool Co. Linoleum Roller. Transporter prevents damage to the roller wheels during transportation to and from the job site. Also acts as a convenient stand when the roller is not in use. Snap button design allows transporter to be rotated on the linoleum roller.

## If your Bon Tool Co. linoleum roller does not have holes in the axle support, you must adapt the roller to accommodate the linoleum roller transporter:

- Drill a 7/16" diameter hole in each end of the axle support. Drill thru both walls as shown in the illustration. (See A below)
- 2. Insert a snap button thru holes in each end of support. (See B below)
- Slide a transporter wheel assembly over each end of the axle support. Align holes and lock in place with a spring clip.

NOTE: Roller can be layed flat as transport wheels are affixed as in photo #1. Do not lay roller handle down to sruface when transport wheels are affixed as in photo #2.





