

INSTRUCTIONS

#24-612 Deluxe Adjustable Knee Kicker

INTENDED USAGE

Knee Kickers should be used for positioning carpet, hooking carpet on tack strip, and light stretching in cramped areas. Use a power stretcher for "stretching-in" rooms, since hard kicking can injure the user and damage carpet.

LENGTH ADJUSTMENT

A press of the button allows the choice of 5 length adjustments from 17-1/2" to 21-1/2". Always check that both sets of buttons are engaged before beginning your kicking.

PIN PENETRATION

The pin adjustment dial gives a visual reference showing pin depth. Set the depth to the approximate carpet thickness. In use, the long pins should reach through the pile into the carpet backing, but not through the backing.

BUMPER PAD ROTATION

The bumper is seamless and is foam-filled. The pad can be turned for an even distribution of wear.

*For more information or to
request a catalog,
call us at 724-443-7080.*

